

A CLEAR SEQUENCE, FROM OPENING TO STORAGE

Set up with confidence.

Use this illustrated overview to plan the work. Follow the manual supplied with your exact canopy frame for its locking, attachment, and anchoring procedures.




Check the hardware before you begin

The illustrations show a spring button frame and example wall brackets. Steel and aluminum models can use different locks, brackets, and fasteners. Confirm the correct manual for the item supplied.


WORK TOGETHER. KEEP HANDS CLEAR.

Open the frame evenly.




01 Place and inspect

Unpack on clear, level ground. Check the frame before use.




02 Partially open

Work with another adult and open opposite sides evenly.



03 Position the top

Align the canopy top with the frame's corners.




04 Continue opening

Keep hands clear of moving hinges. Do not force the structure.


WORK TOGETHER. KEEP HANDS CLEAR.

Secure the top and supports.




01 Engage the correct locks

Use the locking method supplied with your frame. Check every corner.




02 Align the fabric

Seat the corners and keep the fabric clear of joints.



03 Secure the intended attachments

Use only the fabric attachment points intended for that model.



04 Raise evenly

Adjust the legs as instructed and check that all height locks engage.


WORK TOGETHER. KEEP HANDS CLEAR.

Fit the selected walls.




01 Align the back wall

Match the wall to the frame size and intended printed direction.




02 Attach the upper edge

Use the matching attachment system for the supplied top and wall.



03 Check half wall supports

Match brackets to the exact leg profile. The illustrated bracket is one reference design.




04 Secure wall edges

Use the intended supports and straps. Recheck the anchoring after adding walls.


WORK TOGETHER. KEEP HANDS CLEAR.

Pack down with control.




01 Remove extras and lower

Remove flags, wall supports, and other accessories first. Support the frame as the legs are lowered.




02 Release the supplied locks

Follow the frame's release sequence. Do not force a loaded slider.



03 Close the frame evenly

Work from opposite sides and keep hands clear of folding joints.



04 Dry and protect

Pack only dry fabric. Protect the folded frame with its matching bag.