

PARTS & ACCESSORIES

Display Travel and Weight Kit

Select the carry bag, roller bag, sand bag, or water bag needed for your display, with single and multiple accessory quantities.

**WHAT YOU RECEIVE**

- The selected transport or weight accessory
- Selected quantity: one, two, or four
- Product size compatibility review

Selected options define your item. Scene props and other display products are separate.

Choose with confidence.

Choose one accessory type, then its quantity. The name describes a group of available accessories; it does not mean every pictured bag and weight is bundled together.

ACCESSORY

Flag carry bag / Canopy carry bag / Heavy duty roller bag / Sand bag weight / Water bag weight

[View product and available options](#)

DISPLAY TRAVEL AND WEIGHT KIT

Ready for event day.

A practical overview. Use the instructions supplied with your exact product for locks, fittings, mounting, and any model specific procedure.

01 Choose the exact accessory

A roller bag, flag bag, sand bag, water bag, and ground screw perform different jobs. Confirm the selected item.

02 Measure before packing

Match a bag's internal capacity and intended use to the folded frame or pole set. Check its rated load if applicable.

03 Protect printed surfaces

Keep sharp hardware and dirty base components separate from graphics. Pack only clean, dry fabric.

04 Fill weight bags correctly

Use only the filling and attachment method specified for that exact bag. No ballast capacity is assumed in this guide.

05 Position supports carefully

Follow the display's anchoring plan. Do not let weights, bag handles, or ground screws obstruct walkways.

06 Inspect after each event

Check seams, straps, wheels, closures, and anchors for damage before reuse. Empty bags when their care instructions require it.

DISPLAY TRAVEL AND WEIGHT KIT

Get the details right.

Use	Transport and anchoring
Compatibility	Product size confirmed after order
Packing	Individual protective carton

Compatibility information

This accessory does not require a print template. Preserve the selected item, compatible display, packed dimensions, and any load requirement.

Confirm for your exact item

Bag dimensions and capacity, fill specification, attachment method, display compatibility, and anchoring requirements.

[Product downloads and support](#)