

BANNERS

Premium Retractable Banner

A printed banner that retracts into an aluminum base for indoor events, with a support pole and protective carry bag for repeat use.

**WHAT YOU RECEIVE**

- Printed satin fabric graphic
- Retractable aluminum base and support hardware
- Padded Oxford carry bag

Selected options define your item. Scene props and other display products are separate.

Choose with confidence.

Choose the graphic width for the available floor space. An LED banner light is optional; the retractable base remains part of either size.

GRAPHIC

31.5 x 78.7 in / 33.5 x 78.7 in

[View product and available options](#)

PREMIUM RETRACTABLE BANNER

Ready for event day.

A practical overview. Use the instructions supplied with your exact product for locks, fittings, mounting, and any model specific procedure.

01 Choose a level indoor position

Allow room for the cassette base, any stabilizing feet, and the full banner height without blocking a walkway.

02 Prepare the base

Place the cassette on a stable surface. Open any supplied feet according to the model instructions.

03 Assemble the support pole

Seat the matching pole sections and fit the pole securely into the base socket.

04 Raise the graphic carefully

Pull the top rail upward evenly and connect it to the support. Keep hold of the rail against the cassette's spring tension.

05 Check the display

Make sure the base is stable and the graphic is not twisted. Do not open the spring cassette or attempt to retension it.

06 Retract under control

Release the rail while holding it securely, then guide the graphic slowly into the cassette. Pack the dry base and pole in their case.

PREMIUM RETRACTABLE BANNER

Get the details right.

Standard graphic	31.5 in W x 78.7 in H (80 x 200 cm)
Standard model weight	Catalog reference: 9.3 lb (4.2 kg); wider model confirmed separately
Material	Aluminum + satin fabric
Packing	Padded Oxford carry bag

Artwork that fits

The visible graphic and the material retained inside the cassette are different areas. Keep critical text out of the confirmed hidden leader and rail zones.

Confirm for your exact item

Exact cassette model, visible graphic height, leader allowance, top rail method, and replacement graphic compatibility.

Use the matched supplier template before preparing production files. A visual placement preview or layout reference does not establish final bleed, trim, seams, or safe areas.

[Product downloads and support](#)